

COPPER  CHEF.
Bakeware

Features: Nonstick Coating · Dishwasher Safe

Save These Instructions - For Household Use Only
Warranty Information Included



Caution: Hot surfaces when heated.
Read all instructions and safeguards before use.

*Only Use Nonmetallic Utensils

Important Safeguards



- The use of kitchen utensils other than those made specifically for nonstick surface cookware will damage this product and could void your warranty. We recommend using only nonmetallic utensils made of plastic, silicone, wood, or bamboo.
- When using this cooking system, handle all hot surfaces with dry pot holders or cooking mitts. Handling hot cookware with wet cooking mitts or pot holders can produce steam causing serious burns to skin.
- To avoid damage to counter tops and other surfaces, always place hot bakeware on heat resistant trivets or pads.
- Children should not be permitted to use this or any kitchen appliance.
- The Bakeware is coated with a nonstick coating. If this coating appears to be damaged, discontinue use immediately and contact customer service.
- Allow the Copper Chef Bakeware to cool completely before submerging in water. Exposing a hot pan to cool water may cause the pan to warp or produce hot steam and/or splattering hot water that could cause personal injury.

**SAVE THESE INSTRUCTIONS
FOR HOUSEHOLD USE ONLY**

Before First Use



Before first use, wash in warm water with mild, nonabrasive soap. Allow to dry completely. Always follow specific recipe directions for oven time and temperature.

Care & Cleaning



- Although the Copper Chef Bakeware is dishwasher safe, we recommend cleaning by hand.
- Wash with warm water, nonabrasive soap, and a nonmetallic sponge or cloth.
- Do not use baking soda, detergents, or other harsh soaps or solutions.
- Do not use cooking sprays directly on the Copper Chef Bakeware.
- If using under the broiler, watch food closely so it does not overcook.
- We recommend using only nonmetallic utensils made of plastic, silicone, wood, or bamboo.
- Direct exposure to other cook or bakeware can result in unwanted scratches.
- Do not stack or store with any other cook or bakeware unless a protective layer is used.

Manufacturer's Sixty Day Limited Warranty

The manufacturer warrants that all parts and components are free of defects in materials and workmanship for 60 days from the date the product is received. This warranty is valid only in accordance with the conditions set forth below:

1. Normal wear and tear are not covered by this warranty. This warranty applies to consumer use only, and is void when the product is used in a commercial or institutional setting.
2. The warranty extends only to the original consumer purchaser and is not transferable. In addition, proof of purchase must be demonstrated. This warranty is void if the product has been subject to accident, misuse, abuse, improper maintenance or repair, or unauthorized modification.
3. This limited warranty is the only written or express warranty given by the manufacturer. Any implied warranty of merchantability or fitness for a particular purpose on this product is limited in duration to the duration of this warranty. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.
4. Repair or replacement of the product (or, if repair or replacement is not feasible, a refund of the purchase price) is the exclusive remedy of the consumer under this warranty. The manufacturer shall not be liable for any incidental or consequential damages for breach of this warranty or any implied warranty on this product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.
5. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Procedure for Exercise of Warranty Rights:

If warranty service is necessary, the original purchaser must pack the affected product securely and send it postage paid with a description of the defect and date of receipt, proof of purchase, the purchaser's name and mailing address, and a check or money order for \$7.99 per pan to the following address: ***Tristar Products, Inc.***
500 Returns Road, Wallingford, CT 06495.



Distributed by:
Tristar Products, Inc.
Fairfield, NJ 07004
© 2017 Tristar Products, Inc.
973-287-5176
CCBW_IB_TP_ENG_V2_170605